
SUB-METER INSTALLATION DIAGRAM

Meter base must be installed outside of the structure.





Your Touchstone Energy® Cooperative 🖈